

Ningbo Koreo Hydraulic Co.,Ltd.

Address : NO.66,Wengjia Industrial Park,Shangtian Town,Fenghua District, Ningbo City,Zhejiang Province,P.R.China ,315511

TEL.: +86-574-88639848 **FAX.:** +86-574-88639111

Web.: <http://www.keliyy.net>

E-mail: keliyy0574@163.com

CQJ Series

Accumulator Inflatable Tool

Manual Instruction

Ningbo Koreo Hydraulic Co.,Ltd.

● Instructions for use

1、 The utility model is provided with an inflation valve, an exhaust valve, a pressure gauge seat and the body. When the utility model is used, firstly, the chrome protective cap on the upper end of the energy accumulator is screwed on and then the utility model can be used.

2、 **Fill Gas:** the nitrogen gas cylinder and inflation valve (M14X1.5) with high pressure hose assembly connected to the desired pressure can be inflated.

3、 **Exhaust:** In case of accumulator inflation pressure is too high, spin the handle to open the top of the accumulator charge valve, loosen the exhaust valve deflated to the required pressure can be tightened closed.

4、 **Pressure Measurement:** Rotary handle to open the accumulator pressure valve after the top of the exhaust valve to reflect the value. At the same time measurable host pressure, if you need to adjust the pressure, according to the exhaust procedure steps.

5、 Pressure gauge dial position can be freely rotated 360 degrees choice.

6、 Inflatable tools can be used normally or intermittently, selected by the user.

7、 Before remove the inflatable tools, must drain the gas within the inflatable tool to ensure safe use.

● Model Description

Model Example: CQJ - ①

① Equipped with pressure gauge model (16/25/40MPa)

● Pattern Description

